

Xerox® Mobile Scanner

When you're wireless, you're everywhere!

ArchivScanner.de
Competence for Documents
Bennstraße 2, 13053 Berlin
Shop@ArchivScanner.de
Telefon: 030 21 005 22 10

- Wireless – 4GB Eye-Fi® card included
- Wirelessly transmit files to any destination
- Cordless – no computer or cables required
- Rechargeable – over 300 scans per charge
- Functional – Mobile device compatible
- Creates JPG and multi-page PDF files which can be read by any computer

Anyone can use it. Everyone will want it.

We live in a fast paced world and want technology that can keep up with us. We have laptop computers so we can work anywhere. We have smartphones so we can reach out to friends and colleagues anytime. We don't want to be tethered to a desk with cords or to a wall for power. We want convenience and we want it to work without having to think about it. Well, get ready, because it is here.

A truly mobile device in every sense of the word, Xerox Mobile Scanner gives you the power to take the information in your hand, right now, and share it with the world in seconds. The Xerox Mobile Scanner needs no cables or computer to operate. It talks to your PC, Android®, Mac®, iPhone®, iPad®, iPod® touch, or the cloud over Wi-Fi. It lets you send your document anywhere your mobile device will take you and it is as simple as the gesture of handing someone a piece of paper.

As consumers, we have a lot of paper in our lives. We also have a common desire to keep it organised and be able to easily find and share it when needed. However many of us have been hesitant to try scanning it because of the fear that it will be complicated, difficult to manage and time consuming. We have changed that!

The Xerox Mobile Scanner leaves traditional, tethered USB scanners and capture devices far behind.

Communicate when you want to, not when you can.

The Xerox Mobile Scanner is the first mobile, battery operated, cordless scanner that uses Wi-Fi to wirelessly transmit JPEG images and multipage PDF files from the scanner to any destination you want. Simply turn it on, select a file format (colour and B&W PDF, colour JPG) and insert your document. With AutoLaunch technology, scanning begins as soon as documents are inserted into the scanner. A full page takes less than 10 seconds to scan and you can scan 300 pages before needing to recharge the battery.

Xerox Mobile Scanner can handle virtually any medium, including paper, plastic cards, business cards, receipts and photos. Your scanned items can be saved to the included Eye-Fi SD memory card or a USB flash drive. Setting up the Eye-Fi card to wirelessly transfer PDF and JPG images to your PC, Mac, Android, iPhone, iPad or the cloud is a breeze too.

It is time to discover the power of true wireless document sharing.



Xerox® Mobile Scanner



Instantly automatically, effortlessly wireless

Eye-Fi® is the easiest way to organise and transmit anything that you scan. An SDHC memory card that has built-in Wi-Fi stores the images on your card and uses your wireless network to effortlessly transfer files to almost anywhere you want, including online destinations such as Evernote®, Picasa®, Facebook®, Shutterfly® and MobileMe®.

Upon set up, specify which networks the Eye-Fi card uses to transfer your media. Add up to 32 networks for your card to use. The next time your scanner is on and within range of a specified network, your photos and documents will fly to your computer and to your favourite sharing site.

During the quick set-up, you can customise where you want your files sent. The Eye-Fi card will only send them to the device and to the sharing sites you choose.

Transfer anywhere

If you are away from your networks, simply set up Direct Mode. Scan photos or documents wherever you are – then when you're ready to transfer, just turn your scanner on and let Eye-Fi do the rest. The Eye-Fi card will create its own Wi-Fi network and transfer to the free iPhone/iPad or Android app. No matter where you are, you'll get your files on your device in no time. Then use your device's data connection (Wi-Fi, 3G or Edge) to share your content on-the-go – there's 25 sites to choose from. And if you prefer getting backed up and organised automatically, send those files to your computer at home.

| Xerox Mobile Scanner Product Specifications | |
|---|---|
| Xerox® Part No. | 497N01316 |
| Scan Speed | 10 seconds per page |
| Optical Resolution | 300 dpi |
| Removable Media Support | SD card (Class 6, 4 GB Eye-Fi Wireless Card included) and USB Flash Drive |
| Wi-Fi Support | 802.11 b/g/n on 2.4 GHz band (5 GHz band not supported) |
| Wi-Fi Security | Static WEP 64/128, WPA-PSK, WPA2-PSK |
| Wi-Fi Direct Mode | Requires compatible Android or iOS devices + app |
| Mobile OS Support | Mobile apps available for Android and iOS |
| Computer OS Support | Windows® XP® (SP3)/Vista®/7 and Macintosh OS X 10.5 + |
| Supported File Formats | JPG (colour) and multipage PDF (colour and B&W) |
| Smartphone and Tablet Support via USB | Supports mobile devices with media storage including Android®, Apple® iPad® and iPhone®, Blackberry®* and Windows®* smartphones |
| Maximum Document Size | 216 x 297 mm (8.5" x 11.69") |
| Minimum Document Size | 51 x 51 mm (2" x 2") |
| Scanning Media Supported | Paper, plastic cards (embossed), photos |
| Scanning Technology | CIS (contact image sensor) sensor, LED (light emitting diode) light source |
| Real Time Clock | YES for file creation date stamping |
| Airplane Mode | Turns off wireless radio while in flight |
| Bonus Software | PC Connect and Mac Connect scanner utilities, Nuance PaperPort & OmniPage Pro, NewSoft BizCard SE |
| Scans per charge | 300 pages |
| Recharging Time | 8 hours initial charge, 4 hours recharge |
| Dimensions (l x w x h) | 293 x 70 x 51 mm (11.5" x 2.75" x 2") |
| Weight | 638g (22.5 oz) |

*not Eye-Fi compatible

Contents

- Mobile Scanner
- 4 GB Eye-Fi card
- Carrying case
- Recharging/data cable and AC wall adapter
- Bonus software CD
- Cleaning and calibration sheets

For further information please visit: www.xeroxscanners.co.uk

ArchivScanner.de
 Competence for Documents
 Bennostraße 2, 13053 Berlin
 Shop@ArchivScanner.de
 Telefon: 030 21 005 22 10

©2011 Xerox Corporation. All rights reserved. XEROX®, XEROX and Design®, DocuMate® and DocuShare® are trademarks of, or licensed to Xerox Corporation in the United States and/or other countries. Visioneer® and OneTouch® are trademarks of Visioneer, Inc. Nuance® and OmniPage® are trademarks of Nuance Communications, Inc. or its affiliates in the United States and/or other countries. Microsoft®, SharePoint®, Windows Vista®, Windows®, the Windows logo and XP® are trademarks of Microsoft Corporation in the United States and/or other countries. Intel® and Pentium® are trademarks of Intel Corporation in the U.S. and/or other countries. Universal Serial Bus is a trademark of USB Implementers Forum, Inc. (USB-IF). TWAIN™ is a trademark of TWAIN Working Group. All other trademarks are the property of their respective owners and are hereby acknowledged. Prices, features, specifications, capabilities, appearance and availability of Xerox products and services are subject to change without notice. BR2024_497N01316_170112

